




FAQ – CM26_012 Message: "T-Trafo critical" oder "Overtemp Traf"!



Please check on the white transformer all connections.



ATTENTION:
Switch OFF the main supply first!



Nuts must be firmly tightened, but do not overtight! Bolts must well fixed in the casting compound.



NOTE:
A loose connection creates an overheating and destroys the transformer and cables!